



5The E4 miniature encoder is designed to provide digital quadrature encoder feedback for applications with limited space constraints. The E4 utilizes a traditional set-screw encoder disk which accommodates shaft sizes from 1.5mm to 4mm in diameter.

For high quantity OEM applications US Digital offers a cost saving OEM packaging option. When a set-screw is not required, the E4P is the ideal choice for high quantity OEM applications (see the E4P page).

The E4 base provides mounting holes for two #3-48, length 1/4" or two M2.5x.45mm, length 6mm screws on a .586" bolt circle. When mounting holes are not available, a pre-applied transfer adhesive (with peel-off backing) is available for "stick-on" mounting.

The internal components consist of a precision machined aluminum hub and a encoder circuit board module.

The encoder cover is easily snapped onto the base and is embossed with the connector pin-out.

The E4 series encoder can be connected by using a (high retention 4-conductor snap-in polarized 1.25mm pitch) connector. Mating cables and connectors (see the Cables / Connectors page) are not included and are available separately.




#### **Features**

- ▶ Minimum shaft length of .285"
- Fits shaft diameters of .059" to .157" (1.5mm to 4mm)
- → High retention snap-in polarized connector
- ► Accepts .020" (.5mm) axial shaft play
- → Off-axis mounting tolerance of .010"
- ▶ Tracks from 0 to 60,000 cycles/sec
- ▶ 100 to 360 cycles per revolution (CPR)
- → 400 to 1440 pulses per revolution (PPR)
- ▶ 2 channel quadrature TTL squarewave outputs
- > -20 to +100 C operating temperature





## US Miniature Optical Kit Encoder Page 2 of 7



## Environmental

Parameter	Min.	Max.	Units
Vibration (5Hz to 2kHz)	-	20	G
Relative Humidity	-	90	%
Storage Temperature	-40	100	С
Operating Temperature	-20	100	С
ESD (Human Body Model JESD22-A114-A Class 2)	-	3	kV
ESD (Machine Model JESD22-A115-A Class B)	-	300	V

### Mechanical

Parameter	Value	Units	
Moment of Inertia	7.4 x 10^-6	oz-in-s²	
Hub Set Screw Size	#3-48 or #4-48	in.	
Hex Wrench Size	.050	in.	
Hub Setscrew Torque	1.5-2.0	inlbs.	
Mounting Screw Size	#3-48 x 1/4"	-	
M-option Screw Size	M2.5x.45mm, length 6mm	-	
Screw Bolt Circle Diameter	.586 ± .002	in.	






Parameter	Value	Units
Base Mounting Screw Torque	2-3	inlbs.
Required Shaft Length (1)	.285 to .395	in.
Shaft Axial Play	± .020	in.
Off-axis Mounting Tolerance	± .010	in.
Shaft to Mounting Surface Perpendicularity	90 ± 1	deg.
Acceleration	250000 max.	rad/sec²
Technical Bulletin TB1001 - Shaft and Bore Tolerances		Download

<sup>(1)</sup> Includes axial play.

## Electrical

Parameter	Min.	Тур.	Max.	Units	Notes
Power Supply Voltage	4.5	5.0	5.5	V	
Power Supply Current	-	21	27	mA	no load on outputs
High Level Output Voltage	2.4	-	-	V	IOH = -1.2 mA
Low Level Output Voltage	-	-	0.4	V	IOL = 6.0 mA
Rise Time	-	500	-	ns	CL = 25pF, RL = 2.7kOhm
Fall Time	-	100	-	ns	

## Phase Relationship



Parameter	Тур.	Units
Symmetry, S	180 ± 16	electrical degrees
Quadrature Delay, Q	90 ± 12	electrical degrees

A leads B for clockwise shaft rotation, B leads A for counter clockwise shaft rotation viewed from the cover/label side of the encoder.





1400 NE 136th Avenue Vancouver, Washington 98684, USA info@usdigital.com www.usdigital.com Local: 360.260.2468 Toll-free: 800.736.0194



Pin	Description
1	+5VDC power
2	A channel
3	Ground
4	B channel



#### H-option (Hole in Cover)

The **H**-option adds a hole in the cover for the shaft to pass through:

- ▶ For shaft diameters of 1.5mm to 1/8", a 0.170" hole is supplied.
- ► For shaft diameters of 5/32" and 4mm, a 0.295" hole is supplied.

#### L-option (Low Power Strobe)

L-option To reduce the average power requirements, the L-option version of the **E4P** power can be strobed on just long enough to sample outputs A and B. This option is the same as our standard **E4P**, except the internal power bypass capacitor is not installed. The outputs settling time is typically 200 to 400 nano seconds after power up. The minimum sample frequency must be less than the maximum RPM X the CPR / 10.

#### M-option (Metric Mounting Screws)

Provides alternate metric M2.5x.45mm, length 6mm screws. When M-option is NOT specified the default is #3-48 x 1/4" screws.

#### **T-option (Transfer Adhesive)**

When mounting holes are not available, a pre-applied transfer adhesive (with peel-off backing) is available for "stick-on" mounting. Use the centering tool (above) to position the base. **T**-option specifies transfer adhesive.



#### **Centering Tools**

Part #: MCTOOL - (Shaft Diameter\*)

Description: This reusable tool provides a simple method for accurately centering the E4 base onto the shaft.

Material: Aluminum.

Please note: A centering tool is highly recommended when using the T-option transfer adhesive.

\* See Ordering Information below for available Shaft Diameters.

#### **Spacer Tool**

Part #: SPACER-4216

**Description:** This reusable tool is used to properly space the codewheel from the encoder base. Nylon. Round. Provides air gap of 0.07" to 0.03".





**Hex Tools** 

Part #: HEXD-050


Description: Hex driver, .050" flat-to-flat for 3-48 or 4-48 set screws.

Part #: HEXW-050

Description: Hex wrench, .050" flat-to-flat for 3-48 or 4-48 set screws.

### 0


#### **Assembly Instructions**



#### 1. Base Mounting

Place base onto shaft. Secure base to mounting surface using two screws.

**Transfer Adhesive:**Peel off paper backing, place centering tool into center hole of base, slip centering tool onto shaft and slide base and centering tool down onto mounting surface as one piece. Press to form a good bond, then slip centering tool off shaft and continue with standard mounting instructions.



#### 2. Spacer Installation



## US E Miniature Optical Kit Encoder Page 6 of 7

Place spacer tool on optic module as shown below.



#### 3. Codewheel Installation

Slip codewheel onto shaft until it bottoms out against spacer tool. Spacer tool provides an air gap of 0.07" 0.03". Tighten set screw with either the hex wrench / hex driver while pressing down on codewheel.





#### 4. Cover Installation

Place housing (cover) on. With thumb and finger, squeeze ears together to insure that cover fully latches.

# 



CPR	Bore	Power	Cover	Base	Packaging
100	059 =	D =Default	D =Default	D =Default	B =Encoder base, cover, hub/disk
108	1.5mm	L=Low	H =Hole in	M =Alternate metric	assembly, PCB, and screws are all
120	079 =	Power	Cover	M2.5x.45mm,length 6mm screws	packaged separately in bulk. The PCBs a
125	2mm	1 =	T =Transfer Adhesive	in scored	
128	091 =			1 = Each encoder packaged individually.	
200	2.3mm				One spacer tool and one hex driver per 100
250	098 =				encoders.
256	2.5mm				2 = Each encoder packaged individually
	118 =				with one spacer tool and one hex wrench
300	3mm	_			per encoder.
360	125 = 1/8"				3 = Each encoder packaged individually
	156 =				with one spacer tool, one hex wrench, and
	5/32"				one centering tool per encoder.
	157 =				4 = Encoder base, PCB, and screws are pre-
	4mm	lmm		assembled. Base/PCB assembly, cover, and hub/disk assembly are all packaged	

#### **Notes**

- Cables and connectors are not included and must be ordered separately.
- For ordering information please see the Compatible Cables / Connectors section above.
- US Digital warrants its products against defects in materials and workmanship for two years. See complete warranty for details.